

AIM:- To learn IIR filter design using Bilinear Transformation.

SOFTWARE:- Spyder (Python 3.8)

THEORY:-

Steps for designing IIR filter using BLT.

step 1: Prewarp analog frequency using the equation.

$$\Omega = \frac{2}{T_d} \tan\left(\frac{\omega}{2}\right)$$

step 2: Find the order based on appropriate approximation.

for butterworth filter

$$N \geq \frac{\log \sqrt{\frac{10^{0.1K_p} - 1}{10^{0.1K_p} - 1}}}{\log \left(\frac{\Omega_s}{\Omega_p} \right)} = \frac{\log \left(\frac{\lambda}{\epsilon} \right)}{\log \left(\frac{\Omega_s}{\Omega_p} \right)}$$

step 3: To find:

3. Poles of Butterworth filter.

step 4: Find Normalized Transfer function, $H(s)$ for given order.

step 5: Analog to analog frequency transformation.
 $H(s) \Rightarrow H_a(\omega)$.

step 6: Compute digital filter Transfer Function


$$H_a(s) \Big|_{s \rightarrow \frac{2}{T_d} \left(\frac{1-z^{-1}}{1+z^{-1}} \right)}$$

Design an IIR filter with BLT and butterworth approximation using following specifications sampling rate - 8kHz
 PB = 0-500 Hz SB = 2 to 4 kHz PassBand ripples - 3dB.
 SB-ripples \rightarrow 20dB. Sampling frequency. - 8kHz.

$$\omega = \frac{2\pi f}{F_s}$$

$$\omega_p = \frac{2\pi f_p}{F_s} = \frac{2\pi \times 500}{8000} = \frac{\pi}{8}$$

$$\omega_s = \frac{2\pi f_s}{F_s} = \frac{2\pi \times 2000}{8000} = \frac{\pi}{2}$$



step 1: Prewarping the analog frequency.

$$\Omega_p' = \frac{2}{T_d} \tan\left(\frac{\omega_p}{2}\right)$$

$$\text{let } T_d = 2$$

$$\tan\left(\frac{\pi/8}{2}\right) = \underline{\underline{0.198}}$$

$$\Omega_s' = \frac{2}{T_d} \tan\left(\frac{\omega_s}{2}\right)$$

$$= \tan\left(\frac{\pi}{4}\right)$$

$$\boxed{\Omega_s' = 1}$$

step 2: Find order N of Butterworth LPF

$$N \geq \frac{\log \left[\frac{10^{0.1K_s} - 1}{10^{0.1K_p} - 1} \right]}{\log \left(\frac{\Omega_s'}{\Omega_p'} \right)} = \frac{\log \left[\frac{10^{0.1(20)} - 1}{10^{0.1(3)} - 1} \right]}{\log \left(\frac{1}{0.198} \right)}$$

$$N \geq 1.420$$

$$N=2$$

step 3 :- $H(s) = \frac{1}{s^2 + \sqrt{2}s + 1}$

$$H_d(s) \Rightarrow H(s) \Big|_{s \rightarrow \frac{s}{\Omega_c'}}$$

$$\text{where } \Omega_c' = \frac{\Omega_p'}{\varepsilon^{1/N}} = \frac{\Omega_p'}{(10^{0.1 \times P} - 1)^{1/2N}}$$

$$H_d(s) = \frac{1}{\left(\frac{s}{0.198}\right)^2 + \sqrt{2}\left(\frac{s}{0.198}\right) + 1}$$

$$= \frac{0.0392}{s^2 + \sqrt{2}(0.198)s + (0.198)^2}$$

$$H_d(s) = \frac{0.0392}{s^2 + 0.28s + 0.0392}$$

$$H(z) = H_d(s) \Big|_{s \rightarrow \frac{2}{T_d} \left(\frac{1-z^{-1}}{1+z^{-1}} \right)}$$

$$T_d = 2 \text{ sec.}$$

$$\text{Put } s \rightarrow \left(\frac{1-z^{-1}}{1+z^{-1}} \right)$$

$$H(z) = \frac{0.0392}{\left(\frac{1-z^{-1}}{1+z^{-1}}\right)^2 + 0.28\left(\frac{1-z^{-1}}{1+z^{-1}}\right) + 0.0392}$$

$$= \frac{0.0392(1+z^{-1})^2}{(1-z^{-1})^2 + 0.28(1-z^{-1})(1+z^{-1}) + 0.0392(1+z^{-1})^2}$$

$$= \frac{0.0392(1+2z^{-1}+z^{-2})}{1.3272 - 1.92z^{-1} + 0.7135z^{-2}}$$

STEPS OF PROGRAM :

1. Import the required libraries.
2. Define all the filter specifications.
3. Convert the frequency into prewarped frequency.
4. Convert the ~~order~~ filter into Z-domain.
5. Print Numerator and denominator coefficients.
6. Plot the magnitude response of the filter.

CONCLUSION:

1. In this experiment, we have learned to design IIR filter using Bilinear transformation and Butterworth approximation.
 2. The order N by program and analytically is same.
- 